

**LESSON 17 AN/FCC-100(V)7 & 9X PROGRAMMING PORT 1  
FOR SYNC EQUIRATE NRZ 96 KBS CONFIGURATION  
EXAMPLE OF A SIPER NET CIRCUIT**

<b>STEP</b>	<b>OPERATOR ACTION</b>	<b>MESSAGE DISPLAYED</b>	<b>SELECT</b>
1	Press the <b>RESTART</b> key.		
2	Press the <b>NEXT ENTRY P</b> key.	ACTIVATE	
3	Press the <b>NEXT ENTRY P</b> key.	EXAMINE	
4	Press the <b>NEXT ENTRY P</b> key. (Select <b>CONFIGURE</b> using the <b>DOWN B</b> arrow key).	CONFIGURE	<b>CONFIGURE</b>
5	Select <b>OFFLINE</b> using the <b>DOWN B</b> arrow key.	OFFLINE	<b>OFFLINE</b>
6	Select <b>A-CONFIG</b> using the <b>DOWN B</b> arrow key.	A-CONFIG	<b>A-CONFIG</b>
7	If selection displayed is not <b>PORT 1</b> , then scroll through the options by pressing the <b>NEXT ENTRY P</b> key until <b>PORT 1</b> is displayed. (Select <b>PORT 1</b> using the <b>DOWN B</b> arrow key).	SYSTEM  PORT 1	<b>PORT 1</b>
8	If selection displayed is not <b>SYN</b> , then scroll through the options by pressing the <b>NEXT ENTRY P</b> key until <b>SYN</b> is displayed. (Select <b>SYN</b> using the <b>DOWN B</b> arrow key).	SYN	<b>SYN</b>
9	If selection displayed is not <b>EQUIRATE</b> then scroll through the options by pressing the <b>NEXT ENTRY P</b> key until <b>EQUIRATE</b> is displayed. (Select <b>EQUIRATE</b> using the <b>DOWN B</b> arrow key).	EQUIRATE	<b>EQUIRATE</b>
10	If selection displayed is not <b>96K</b> then scroll through the options by pressing the <b>NEXT ENTRY P</b> key until <b>96K</b> is displayed. (Select <b>96K</b> using the <b>DOWN B</b> arrow key).	XXX 50 to 768K	<b>96K</b>

**LESSON 17 AN/FCC-100(V)7 & 9X PROGRAMMING PORT 1  
FOR SYNC EQUIRATE NRZ 96 KBS CONFIGURATION  
EXAMPLE OF A SIPER NET CIRCUIT**

<b>STEP</b>	<b>OPERATOR ACTION</b>	<b>MESSAGE DISPLAYED</b>	<b>SELECT</b>
11	If selection displayed is not <b>CL-HIGH</b> then scroll through the options by pressing the <b>NEXT ENTRY P</b> key until <b>CL-HIGH</b> is displayed. (Select <b>CL-HIGH</b> using the <b>DOWN B</b> arrow key).	CL-HIGH CL-RTS-DCD CL-DTR-CTS	<b>CLK-HIGH</b>
12	If selection displayed is not <b>RX-INT</b> then scroll through the options by pressing the <b>NEXT ENTRY P</b> key until <b>RX-INT</b> is displayed. (Select <b>RX-INT</b> using the <b>DOWN B</b> arrow key).	RX-INT RX-EXT	<b>RX-INT</b>
13	If selection displayed is not <b>TX-INT</b> then scroll through the options by pressing the <b>NEXT ENTRY P</b> key until <b>TX-INT</b> is displayed. (Select <b>TX-INT</b> using the <b>DOWN B</b> arrow key).	TX-INT TX-EXT	<b>TX-INT</b>
14	If selection displayed is not <b>MINIMUM</b> then scroll through the options by pressing the <b>NEXT ENTRY P</b> key until <b>MINMUM</b> is displayed. (Select <b>MINMUM</b> using the <b>DOWN B</b> arrow key).	CENTERED MINIMUM	<b>MINIMUM</b>
15	If selection displayed is not <b>NEG-MARK</b> then scroll through the options by pressing the <b>NEXT ENTRY P</b> key until <b>NEG-MARK</b> is displayed. (Select <b>NEG-MARK</b> using the <b>DOWN B</b> arrow key).	POS-MARK NEG-MARK	<b>NEG-MARK</b>
16	Press <b>STORE</b> to " <b>save</b> " this <b>SYN PORT 1 CONFIGURAION</b> into the <b>OFFLINE A-CONFIG</b> memory.	SYN	

**END OF AN/FCC-100(V)7 & 9X PORT 1 SYN  
EQUI NRZ 96 KBS CONFIGURATION  
EXAMPLE OF A SIPER NET CIRCUIT**